


**1959 PASSENGER CAR AND TRUCK
ACCESSORIES INSTALLATION
REFERENCE MANUAL**



Product Knowledge Helps Sell Accessories

KNOW YOUR PRODUCT

**987950
SEAT BELT**



CHEVROLET PASSENGER CAR

© 1958 Chevrolet Division
General Motors Corp.




FIG. 1 TWO PASSENGER FRONT SEAT BELT




FIG. 2 THREE PASSENGER FRONT SEAT BELT

FRONT SEAT INSTALLATION

- STEP 1** REMOVE THE REAR SEAT CUSHIONS ON ALL MODELS EXCEPT THE STATION WAGONS.
- STEP 2** LOCATE AND DRILL 13/32 INCH DIAMETER HOLES THROUGH THE FLOOR PAN AS REQUIRED. SEE CHART AND FIGURE 3.
- STEP 3** INSTALL A BRACKET, SPECIAL FLAT WASHER, BOLT, AND TWO NUTS AT EACH DRILLED HOLE. APPLY WINDSHIELD SEALER TO AREAS SHOWN BEFORE INSTALLATION. SEE FIGURE 4.
- STEP 4** ON TWO DOOR MODELS THREAD THE CENTER

- SEAT BELTS THROUGH THE SEAT CREVICE AND ATTACH TO CENTER BRACKETS, AS SHOWN IN FIGURE 1. ATTACH BELT HOOK TO SIDE OF SEAT AS SHOWN IN VIEW A.
- STEP 5** ON FOUR DOOR MODELS FRONT SEAT BACK MUST BE SLIT AND FURNISHED PATCH CEMENTED IN POSITION AS SHOWN IN VIEW C, FIGURE 1. THREAD SEAT BELTS THROUGH PATCH AND ATTACH TO CENTER BRACKETS AS SHOWN IN VIEW C AND D. ATTACH BELT HOOK TO PILLAR AS SHOWN IN VIEW B, FIGURE 1.
- STEP 6** REPLACE REAR SEAT CUSHION IF INSTALLING FRONT SEAT BELTS ONLY.




FIG. 3 BRACKET LOCATIONS

MODEL	FRONT SEAT 2 PASS. 3 PASS.	REAR SEAT 2 PASS. 3 PASS.	INT. SEAT 2 PASS. 3 PASS.
4 DOOR SEDAN	A B C	D H G	
4 DOOR SPORT SEDAN	A B C	D H G	
2 DOOR SEDAN	A B C	D H G	
CONVERTIBLE	A B C	E F	
SPORT COUPE	A B C	E F	
UTILITY SEDAN	A B C		
6 PASS. STA. WAGON	A B C	F J G	
9 PASS. STA. WAGON	A B C	SEE SHEET 5	F J G
SEDAN DELIVERY	A B C	* IF R. P. O. SEAT EXISTS	
PICK-UP DELIVERY	A B C		
CARRYALL		SEE PAGE 96	SEE PAGE 96






FIG. 4 BRACKET INSTALLATION



REAR SEAT INSTALLATION

STEP 7 REMOVE THE REAR SEAT CUSHION AND BACK REST. ON STATION WAGONS, FOLD THE REAR OR INTERMEDIATE SEAT TO LOAD PLATFORM POSITION.

STEP 8 LOCATE AND DRILL 13/32 INCH DIAMETER HOLES THROUGH THE FLOOR PAN AS REQUIRED. SEE CHART AND FIGURE 3. FOR STATION WAGONS ALSO SEE VIEW A.

STEP 9 INSTALL A BRACKET, SPECIAL FLAT WASHER, BOLT AND TWO NUTS AT EACH DRILLED HOLE. APPLY

WINDSHIELD SEALER TO AREAS SHOWN BEFORE INSTALLATION. SEE FIGURE 4,

STEP 10 ATTACH THE SEAT BELTS TO THE BRACKETS. REPLACE THE SEAT BACK REST AND CUSHION, ON STATION WAGONS FOLD THE SEAT CUSHIONS BACK TO SEAT POSITION.

STEP 11 THREAD THE CENTER SEAT BELTS THROUGH THE SEAT CREVICE. SEE FIGURE 5 AND 6.




FIG. 7 NINE PASSENGER STATION WAGON REAR SEAT




FIG. 8 NINE PASSENGER STATION WAGON REAR SEAT BELTS

REAR SEAT INSTALLATION

STEP 12 FOLD REAR SEAT CUSHION TO LOAD PLATFORM POSITION TO PROVIDE ACCESS TO FLOOR PAN.

STEP 13 DRILL 13/32 INCH DIA. HOLES THROUGH FLOOR PAN AS SHOWN BY DIMENSIONS IN FIGURE 7. SEE CHART FOR TWO AND THREE BELT INSTALLATION.

STEP 14 INSTALL A BRACKET, SPECIAL FLAT WASHER, BOLT AND TWO NUTS AT EACH DRILLED HOLE. APPLY WINDSHIELD SEALER TO AREAS SHOWN BEFORE INSTALLATION. SEE FIGURE 4.

STEP 15 ATTACH SEAT BELTS TO THE BRACKETS AND RETURN SEAT TO NORMAL POSITION, THREADING THE BELTS THROUGH SEAT CREVICE. SEE FIGURE 8.

STEP 16 ATTACH BELT HOOK AS SHOWN IN FIGURE 8.






FIG. 12 BELT BUCKLE OPERATION PROCEDURE

RECOMMENDED ADJUSTED BELT LENGTH X			
		BUCKLE	CATCH
2 Door Sedan	Front	39"	33"
	Rear	30"	17"
4 Door Sedan	Front	39"	33"
	Rear	30"	17"
Sport Coupe	Front	39"	33"
	Rear	39"	17"
Convertible	Front	39"	33"
	Rear	30"	17"
Sta. Wagon 2 & 4 Door	Front	39"	33"
	Rear	30"	25"
9 Passenger Sta. Wagon	Front	39"	33"
	Intermediate	35"	25"
Pickup & Sedan Del.	Front	39"	19"
			33"



VIEW A



PLACE THIS PAGE IN GLOVE COMPARTMENT

FIG. 13 BELT ADJUSTMENT